

Bona Premium Spray Mop

for Wood Floors

All-in-one solution for cleaning your wood floors





Easy to Change Pad
The mop has Velcro strips that
hold the pad in place but make
it easy to attach and remove.



Extra-Large Mop Head
Cleans 40% faster than the
leading competitor, based on
usable cleaning surface area, so
you can get the job done faster.

Bona Premium Microfiber Floor Mop is a spray mop that combines a convenient cartridge containing Bona Wood Floor Cleaner with the Bona Microfiber Cleaning Pad, providing the ultimate care and protection for sealed wood floors. The pH-neutral formula is ready to use, dries quickly and leaves behind nothing but a streak-free natural shine. Forget about filling up a messy bucket - just spray for a quick and effective clean.

- Ergonomic light-weight design
- Extra-large baseplate for fast effective cleaning
- Soft, flexible corners protect furniture and skirting boards
- Refillable bottle
- Hook for easy storage

Pack contains:

- Bona Premium Spray Mop for Wood Floors
- Bona Wood Floor Cleaner refillable bottle (850 ml)
- Bona Microfiber Cleaning Pad





Bona Premium Spray Mop

for Wood Floors

All-in-one solution for cleaning your wood floors

PREPARATION

First, remove all loose dust and dry dirt from your floor using a Bona Microfiber Dusting Pad or a vacuum cleaner.

INSTRUCTIONS FOR USE

See package for instructions on initial assembly.

Insert Bona refillable cleaner bottle into the Spray Mop. Press it firmly into its socket until you hear a click.

Attach the cleaning pad to the mop head. The grey rubberised corners of the mop head should face forward.

Mist cleaner onto a section of the floor and then wipe clean. Continue to clean the floor section by section. Rinse and wring out cleaning pad as it becomes soiled.

On stubborn spots, spray cleaner directly onto the spot and let it work a few minutes before scrubbing and wiping off.

When it is time to refill your bottle, just press the release button for easy removal of bottle and refill with Bona Wood Floor Cleaner

Cleaning Pad can be washed in 60°C up to 500 times. Do not use fabric conditioner.



Avoid leaving your mop standing with a wet cleaning pad face-down on the floor surface when done cleaning - this may cause permanent damage to your surface.

For more information, please visit bona.com

